

Guiding your way to great entertainment An all-in-one Singtel TV Starter Guide

Welcome to your new Singtel TV

You are about to discover the latest and the most exciting TV entertainment. Find out everything you need to get started in this guide – from recording the entire series or multiple programmes simultaneously to managing recordings on-the-go and even pausing and replaying your favourite shows.

Power on your set-top box now to unlock a world of awesome TV entertainment.

Table of Contents



>>> Fast Forward To Your Faves

| Over | rview | | | | |
|----------|---------------------|--------------------------|------------------------|--|----|
| i | Remote Control | | | | 2 |
| | | | | | |
| | nnel Guide | | | | |
| | Show Timings | | | | 3 |
| | Showtimes (for spec | ific channel) | Showtimes (for sp | becific day) | |
| Easy | Browsing | | | | |
| I | Favourites | | | | 4 |
| | How to Organise You | ur Favourites | | | |
| Rem | ote Control | | | | |
| | | oom, Remote Pairing | | | 5 |
| | | - | | | |
| i | | ~ ~ | | | 6 |
| | Functions: 🔇, 📎, | | | | |
| | | | | | |
| Easy | Access | | | | |
| I | Quick Access | | | | 8 |
| | Yellow Button | Catch-Up | Recommended for You | Channel Store, 4D/ TOTO and Big Sweep, Shares, Netflix | |
| E | Recording | | | | 10 |
| | | How to Stop Recording | | | |
| | | via DVR Set-Top Box | | | |
| i | Video on Demand | (VOD) | | | 12 |
| | | How to Retrieve Purcha | | | |
| | 1.00 | | | | |
| Cust | omisation | | | | |
| | Parental Control | | | | 13 |
| | Parental Lock | Rental Lock | R21 Lock | | |
| Tips | | | | | |
| <u>.</u> | Troubleshooting | | | | 14 |
| | Issues with | Better WiFi Connectivity | | | |
| | TV Service | | | | |
| Usef | ul Information | | | | 16 |
| ÷ | | I Manad Mana T. C | | | |
| 1 | Any Queries? | Need More Information | on singtel 1 V? | Want to Enhance your TV experience? | |


1

(2)

Learn how to access your Singtel TV features.

) Remote Control

Know your remote control shortcuts for easy access to TV features such as Search, Record, Programme Guide and more



Learn how to access your favourite shows.

Show Timings

Check the showtime of your favourite programmes, add shows and channels to your Favourites, and much more

Showtimes (for specific channel)

STEP 1 Press **GUIDE** on remote control



- **STEP 2** Press $(\mathbf{O}, \mathbf{O}, \mathbf{O}, \mathbf{O})$ on your remote control to select the specific time slot & specific channel
- STEP 3 Press (on remote control to view the selected channel

Showtimes (for specific day)

- **STEP 1** Press **GUIDE** on remote control and then press the **OPTION** button
- STEP 2 Select Jump to Day & Time and press (or)
- **STEP 3** Press \triangle and \bigtriangledown to select the specific day and then press \bigotimes

Easy Browsing

Favourites

Curate the list of your most-watched channels and shows


How to Organise Your Favourites

- **STEP 1** Press **GUIDE** on remote control and then press the **OPTION** button
- **STEP 2** Select from the following features to organise your favourite shows and channels
- Want to create a list of your most-watched channels instead of scrolling and navigating? To include a channel to your list of favourites, select your favourite channel and press **Add to Favourites**
- Want to see all your favourite channels? Select Favourite Channels and press (3). Then select My Favourite and press (3) to view the list of your most-watched channels.
- To remove channels from My Favourite list, select Remove from Favourite and press (R)

Remote Control

Find out how to manage your Singtel TV Settings.

🛶 Subtitles



- STEP 2 Go to Zoom and press 🛞
- STEP 3 Choose the optimum setting (Normal, Stretch, Zoom 1, Zoom 2, Zoom 3) and press @



Remote Pairing

How to Use Singtel TV GO as a Remote Control

- **STEP 1** Go to **Singtel TV GO*** on your mobile device
- **STEP 2** Ensure your mobile device's WiFi is connected to the same network as your Set-Top Box
- **STEP 3** Select ^a and go to **Settings**
- STEP 4 Click on Remote Pairing Setup and choose Setup Now when prompted
- **STEP 5** Once the app prompts that the pairing is successful, your mobile device can be used as a remote control

(5)

*Turn to Page 11 to find out how to record with Singtel TV GO

Learn how to browse with ease.

Select from a list of TV features to navigate with ease

1. **1**

- **STEP 1** Press **(**) on remote control
- **STEP 2** Select from the following functions: Search, Channel Guide, Favourites, Catch-Up*, Recorded TV, Store, Settings

*View Catch-Up for all your subscribed channels



2.

6

- **STEP 1** Press **>** on remote control
- **STEP 2** Select from the following functions: Add to Favourites/Remove from Favourites, View Favourites, Change Favourites, Audio Languages, Subtitle Languages, Zoom



Remote Control


Learn how to browse with ease.







- **STEP 1** Press ♥ on remote control to browse information about current programme
- **STEP 2** Press **O** or **O** to browse programme information on other channels



(7)

Quick Access Discover a suite of useful features at the touch of a button

Yellow Button

- STEP 1 Press (C) Yellow Button on remote control
- **STEP 2** Select from the following functions: Catch-Up, Netflix, Recommended for You, VOD, 4D/TOTO, Shares, Channel Store on the Quick Access bar.



- Catch-
- Up*
- 1 Select Catch-Up and press ()
- 2 Select the show you would like to watch and press ()



3 Select **Play** and press (**r**) to watch

*For channels with Catch-Up viewing

Recom-1 Select **Recommended** and press ()

for You


(8)

- mended 2 A list of recommended channels will be shown. Select the specific channel and press () to view



Channel Store

- 1 To view the channels that you are subscribed to, go to **Channel Store** and press (**•**)
- 2 Click on My Channels and press ()



| 4D/TOTO and Big Sweep | 2 S | Select 4D/TOTO and press 🛞 Select from 4D, TOTO and Big Sweep Choose the respective draw date for the results |
|-----------------------------|-----|--|
| Shares | 2 S | Select Shares and press 🛞 Select Agree and press 🛞 to proceed, or select Exit and press 🛞 to quit |
| Netflix | 1 5 | Select Netflix and press 🛞 |

Recording

Record your favourite shows via your DVR Set-Top Box or remotely with Singtel TV GO

1. How to Record via DVR Set-Top Box

| STEP 1 | Press the Guide button |
|--------|---|
| STEP 2 | Select the particular show which you would like to record |
| STEP 3 | Press Record on remote control |
| STEP 4 | A Recording Message prompt is shown |
| STEP 5 | To schedule recording for the entire series, press 🔘 Record again |
| STEP 6 | Press Record once more to cancel recording |
| | - |

2. How to Stop Recording via DVR Set-Top Box

| STEP 1 | Select Recorded TV |
|--------|---|
| STEP 2 | Select the show you would like to stop recording |
| STEP 3 | Select Stop Recording |
| STEP 4 | Choose to Play, Keep until or Erase after recording has stopped |
| | |

3. How to Go to Recorded TV

| STEP 1 | Press Recorded TV on remote control or press 🔇 on remote control |
|--------|---|
| | and go to Recorded TV and press 🕅 |

STEP 2 Select By Date or By Title and select the recorded show

| Play | 1 | Select Play and press or to play the show |
|---------------|--------|--|
| Keep Until | 1 2 | Select Keep Until and press (*) Select Space needed or I erase . Select Don't change to exit without changes |
| Erase | 1 2 | Select Erase , select Confirm and press to erase Select Cancel and press to keep the show |

Don't have a DVR Set-Top Box? Call **1609** to upgrade now!

4. Remote Recording via DVR Set-Top Box

To Set Up Remote Recording in TV

- 1 Press Menu in remote control
- 2 Go to **Settings** and press (**W**)
- 3 Go to Remote Recording and press 🔿
- 4 Go to User Name and press 🔿
- 5 Choose your User Name (please use 8 characters)
- 6 Create **PIN** (6-8 Digits) and confirm your **PIN** by selecting **Confirm** and press (**a**)

To Set Up Remote Recording in Singtel TV GO*

- 1 Download the **Singtel TV GO** app on your device
- 2 Go to Settings
- 3 Go to Account Setup
- 4 Go to Remote TV Recording
- 5 Fill in User Name and PIN (as per set-up in TV)

Remote Recording in Singtel TV GO

- 6 Once set up, you can log into Singtel TV GO
- 7 Select the programme to be recorded
- 8 DVR Set-Top Box must be powered on or in standby mode



*Complimentary for Singtel TV subscribers

Did you know?

You can access the **Sports Portal** feature on **Singtel TV GO** for **FREE!** Look out for football games fixtures, videos, news, player rankings, team information and table of scores! Never miss a match again when you set reminders for upcoming matches!

(11)



1. How to Purchase VOD

Easy Access



- **STEP 2** Move $(\mathbf{A}, \mathbf{V}, \mathbf{S}, \mathbf{S})$ to choose the video to be purchased and press (\mathbf{A}) to select
- **STEP 3** Select **Rent** to purchase the video
- **STEP 4** Press **Rent Now** to complete the purchase

2. How to Retrieve Purchased VOD

- **STEP 1** Press Video on Demand on remote control
- **STEP 2** Go to My Rentals

(12)

- STEP 3 Go to Current Rental and press ()
- **STEP 4** Select **Resume** to continue the VOD viewing
- STEP 5 Or select Restart to restart the VOD

Customisation

Parental Control

| | How | to | Set | Parental | Control |
|--|-----|----|-----|----------|---------|
|--|-----|----|-----|----------|---------|

- **STEP 1** Press (Menu) or **S** on remote control
- **STEP 2** Go to Settings

1. Parental Lock

Protects your children from consuming undesirable content. Set locks on NC16 or M18 content (based on MDA ratings), or on specific channels.

| STEP 1 | Under Parental Control, select 🛱 Parental Lock |
|--------|--|
| STEP 2 | Enter your default 4-digit PIN "1234" |
| STEP 3 | Go to Change PIN |
| STEP 4 | Enter your new 4-Digit PIN " [* * * *] " |
| STEP 5 | Enter your 4-Digit PIN " $(\times \times \times)$ " to confirm the changes |
| STEP 6 | If you forget your PIN, call 1688 for more information |

2. Rental Lock

Prevents unintended purchases by locking VOD and Channel Store.

| STEP 1 | Under Parental Control, select | Rental Lock |
|--------|--------------------------------|-------------|
|--------|--------------------------------|-------------|

- **STEP 2** Set PIN
- **STEP 3** Enter your default 4-digit PIN "1234"
- **STEP 4** Go to Change PIN
- **STEP 5** Enter your new 4-Digit PIN " ********
- **STEP 6** Enter your 4-Digit PIN " $\times \times \times$ " to confirm the changes
- STEP 7 If you forget your PIN, call 1688 for more information

3. R21 Lock

Locks R21 content by default to prevent children under 21 years old from watching it.

STEP 1 Under Parental Control, select R R21 Lock

STEP 2 As it is locked by default, call 1688 to acquire password so that you can unlock R21 content.

(13)

(14

E Troubleshooting

Pick up quick tips on troubleshooting issues with your TV service and maximising your home entertainment

Issues with TV Service

If you encounter an error message on your TV screen, follow the tips below to reboot your TV equipment.

STEP 1 Power off your devices in the following sequence

- 1 Set-Top Box
- 2 Optical Network Router (ONR)

STEP 2 Power on Optical Network Router (ONR)

Ensure POWER and PON LED indicators are lighted



STEP 3 Power on Set-Top Box



• Avoid overheating by placing your devices in an open area.

- Keep your Set-Top Box on standby mode when it's not in use.
- Ensure all connecting ends of cables are intact and tightly plugged into the power outlets.

Call 1688 if you require more information.

Tips

Need WiFi Mesh for your home? Call **1609** to find out more!

Better WiFi Connectivity

Optimise WiFi connectivity at home with these useful tips below.

Tip 1 Reposition your router

- Place your router in a clear and clutter-free central area and avoid placement on the floor
- To extend your home WiFi coverage, add on a WiFi Mesh Basic Dual Pack



Tip 2 Check for WiFi congestion

- 1 Use the Singtel WiFi Analyzer to see if your network is congested. Visit **www.singtel.com/globalutilities** and select WiFi Analyzer
- 2 Select "Start scan"
- 3 If you see a "Moderate" result, you may be facing WiFi congestion

To reduce congestion

- 1 Go to your router's Wireless Settings page
- 2 Under Router Setup > Channel, select Auto Mode and click Save
- 3 Reboot your router by turning it off and on
- 4 Now your router can automatically scan and connect to the least congested WiFi channel

Tip 3 Consider wireless dual-band routers

- Different devices support different WiFi frequencies
- When many neighbouring WiFi network or wireless devices run on the same 2.4GHz frequency, congestion may happen
- A dual-band router can help ease congestion as it supports 2 frequency bands (2.4GHz and 5.0GHz)

For more tips on maximising your WiFi connectivity, visit singtel.com/wifimaster

(15)

Any Queries?



Call 1688

Speak to our friendly customer service officers regarding billing enquires, troubleshooting, technical assistance and other general enquiries.

Need More Information on Singtel TV?



Visit singteltv.com.sg

Get comprehensive information on Singtel TV including the monthly showtime guide, highlights, terms and conditions, events and promotions.

Want to Enhance Your TV Experience?

Subscribe to our other exciting TV content packs, recontract or purchase TV value-added services.



Visit Singtelshop.com/singteltv



Call 1609



Or drop by any of these Singtel Shops!

Central

BUGIS JUNCTION #01-50/50A COMCENTRE #01-00 Comcentre 2

North

ANG MO KIO HUB #B1-54/55/56/57 CAUSEWAY POINT #03-03/04/05 WATERWAY POINT #B1-30

West

JURONG POINT #B1-98/99

East

PARKWAY PARADE #B1-01/02 TAMPINES MALL #02-13/14/15

Visit **Singtel.com/Store-Locator** for the complete list of Singtel Shops and Singtel Exclusive Retailers.

(16)



